



1) Start by drawing a line horizontally from the pin hole of your receiver outward. 2) Then draw a vertical line from the center of the ball on your atv downward until it intersects with the other line. The vertical line can be no more than 16.25" from the pin hole of the receiver & the horizontal line can be no more than 37.5" from the top of the ball on your atv. Other notes: 3) The extra receiver will be 10" higher than your original receiver. 4) the ball of the atv will be 9" from where you mount the upright arm and will determine the placement of the atv on the back of the truck.